



ROSCALATA CABEZA PAN RANURA PHILLIPS

Código	Diámetro	Largo "L", pulg	Envase	Diámetro "A" Cabeza, mm	Altura "H" Cabeza, mm	Diámetro Perfor Piloto (mm)	Rango a Roscar	Torque Instalación (Nm)
Zincado Brillante								
03RLBP	#4	1/4	100 U	5,3	1,9	2.3 - 2.5	0.4 - 1.5 mm	1,46
04RLBP								
05RLBP								
06RLBP								
07RLBP								
08RLBP	#6	1/4	100 U	6,6	2,3	2.7 - 3.0	0.4 - 1.9 mm	2,7
09RLBP								
10RLBP								
11RLBP								
12RLBP								
13RLBP								
14RLBP								
46RLBP								
47RLBP								
15RLBP								
17RLBP	#8	3/8	100 U	7,9	2,8	3.2 - 3.5	0.6 - 1.9 mm	4,4
18RLBP								
19RLBP								
20RLBP								
21RLBP								
22RLBP								
23RLBP								
24RLBP								
42RLBP								
50RLBP								
51RLBP	#10	3"	100 U	9,2	3,2	3.7 - 4.0	0.5 - 3.2 mm	6,32
25RLBP								
26RLBP								
27RLBP								
28RLBP								
29RLBP								
30RLBP								
02RLBP								
43RLBP								
52RLBP								
53RLBP	#12	3"	100 U	10,5	3,7	4.3 - 4.8	0.6 - 3.2 mm	9,94
31RLBP								
32RLBP								
33RLBP								
34RLBP								
35RLBP								
36RLBP								
44RLBP	1/4	1"	100 U	12,2	4,3	5.0 - 5.5	0.8 - 4.7 mm	16
37RLBP								
38RLBP								
39RLBP								
40RLBP								
41RLBP								
45RLBP								

